

E5CZ OMRON Temperature Controller

Instruction Manual

Introduction

Thank you for purchasing this OMRON product. Read this instruction manual and thoroughly familiarize yourself with the function and characteristics of the product before using it. This product is designed for use by qualified personnel with knowledge of electrical systems. Keep this instruction manual for future reference.

OMRON Corporation
© All Rights Reserved

For detailed operation instruction manual, please refer to the E5CZ User's Manual.

Safety Precautions

Key to Warning Symbols

CAUTION Indicates a potentially hazardous situation which, if not avoided, is likely to result in minor or moderate injury or property damage. Read this manual carefully before using the product.

CAUTION

The service life of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the product within the rated load and electrical service life. Using the product beyond its service life may occasionally result in contact welding or burning.

CAUTION - Risk of Fire and Electric Shock

- This product is UL listed as Open Type Process Control Equipment. It must be mounted in an enclosure that does not allow fire to escape externally.
 - More than one disconnect switch may be required to de-energize the equipment before servicing.
 - Signal inputs are SELV, limited energy.
 - Caution: To reduce the risk of fire or electric shock, do not interconnect the outputs of different Class 2 circuits.
- Do not touch the terminals while power is being supplied. Doing so occasionally result in minor injury due to electric shock.
- If operating improperly, it will cause minor or moderate injury, or property damage.
- Do not allow pieces of metal, wire clippings, or fine metallic shavings or filings from installation to enter the product. Doing so may occasionally result in electric shock, fire, or malfunction.
- Do not use the product in locations where flammable or explosive gases are present. Doing so may occasionally result in minor or moderate explosion, causing minor or moderate injury, or property damage.
- Do not attempt to disassemble, repair, or modify the product. Doing so may occasionally result in minor or moderate injury due to electric shock.
- Tighten the screws on the terminal block using the tightening torque within the following ranges (0.74-0.90N.m). Loose screws may occasionally cause fire, resulting in minor or moderate injury or damage to the equipment.
- Perform correct setting of the product according to the application. Failure to do so may occasionally cause unexpected operation, resulting in minor or moderate injury, or damage to equipment.

Ensure safety in the event of product failure by taking safety measures, such as installing a separate overheating alarm system. Product failure may occasionally prevent control operations or alarm output, resulting in damage to the connected facilities and equipment.

Be sure that the platinum resistance thermometer type and the input type set on the Temperature Controller are the same.

Suitability for Use


OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product. Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product. NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

Precautions for Safe Use

- Do not use the following locations:
 - Locations where water or oil may splatter on the Temperature Controller
 - Locations where directly exposed to sunlight
 - Locations where dust or corrosive gas is present (in particular, sulfur or ammonia gases)
 - Locations subject to sudden or extreme changes of temperature
 - Locations where condensation or ice may form
 - Locations subject to strong shocks and vibration.
- To reduce the risk of fire of electric shock, install in a controlled environment relatively free of contaminants.
- Use and store the Temperature Controller within the specified ambient temperature and humidity ranges. If necessary, cool the Temperature Controller.
- Do not prevent heat dissipation by obstructing the periphery of the Temperature Controller. Do not block the vents on the Temperature Controller.
- Use the specified size of crimp terminals (M3.5 width: 7.2mm max.) to wire the terminal block.
- To connect bare wires to the terminal block, use AWG24 to AWG18. (Length of exposed wire: 5 to 6mm)
- Be sure to confirm the name and polarity for each terminal before wiring the terminal block.
- Do not connect anything to unused terminals.
- The voltage output (control output) is not electrically isolated from the internal circuits. When using a grounded temperature sensor, do not connect any of the control output terminals to ground. Otherwise unwanted current paths will cause measurement errors.
- Install the Temperature Controller as far away as possible from devices that emit strong, high-frequency energy or devices that cause surges. Keep the Temperature Controller wiring separate from high-voltage, high-current power lines. Avoid connecting in parallel with a power line or on the same line as a power line.
- The power supply voltage and load must be within the rated and specified ranges.
- Use a switch, relay, or other contact so that the power supply voltage reaches the rated voltage within 2 seconds. If the applied voltage is increased gradually, the power supply may not reset or malfunctions may occur.
- When executing self-tuning, turn ON the power of load (e.g. heater) simultaneously or before turning on the Temperature Controller.
- After turning on the power, the temperature controller will start until 2 seconds, please give enough consideration of control circuit setup.
- Install a switch or circuit breaker that allows the operator to immediately turn off the power, and label suitably.
- Allow a warm-up time of at least 30 minutes.
- The output may turn OFF when shifting to certain levels. Take this into consideration when performing control.
- After turning off the power, the connection points of switch and relay can not decrease the voltage slowly, this can avoid the wrong action and storage error.
- When extending the thermocouple lead wires, always use compensating conductors suitable for the type of thermocouple. Do not extend the lead wires on a platinum resistance thermometer. Use only low-resistance wire (5 Ω max. per line) for lead wires and make sure that the resistance is the same for all three wires.
- Please make sure that the installation of OPTION UNITS must be correct. When installing, you shouldn't take the internal PCB out.
- When drawing out the controller from the case, do not apply force that would deform or alter the Product.
- When drawing out the controller from the case to replace the Product, check the status of the terminals. If necessary, replace the rear case as well.
- When inserting the controller into the case, if it is hard to do, please stop it. Because it will damage the other internal parts.
- If you never to draw out the Temperature Controller, turn off the power first. Never touch the terminals or the electronic components, or subject them to physical shock. When inserting the Temperature Controller, do not allow the electric components to contact the case. Do not touch the electronic components or patterns on the board with your hand. Hold the Temperature Controller by the edge of the front panel when handling it.
- The number of EEPROM write operations is limited. Therefore, use RAM write mode when frequently overwriting data during communications or other operations.
- Do not use paint thinner or similar chemical to clean with. Use standard grade alcohol.
- Use tools when separating parts for disposal.

Wiring


Dimensions (mm)




In the pack:
- Main unit *1
- Adapter *1
- Instruction manual *1
- Check out paper *1

Solderless terminal size: M3.5

Names of parts on front panel




Installation



- Insert the controller through the mounting hole in the panel (1.4mm thickness). Push the adapter on from the rear and fasten temporarily, removing any gap between the controller, plane and adapter. Finally, secure two fixing screws.
- When more than one machine is installed, make sure that the ambient temperature does not exceed the specified limit.
- Close side-by-side mounting is possible in one direction only, either horizontally or vertically.

Connections (The applicability of the electric terminals varies with the type of machine.)



- OPTION UNIT is applicable only to models E5CZ-□2M□□.
- For detail function of OPTION UNITS, please refer to the "E5CZ OPTION UNITS instruction manual".
- For the product of E5CZ-C2M, E5CZ-C2M adding OPTION UNITS of E53-CN03 or E53-CN01 satisfy the standard of EN61326 CLASS A in limit of radiated interference field strength test, please add clamp filter in the power line of temperature controller (TKZCAT2235-1030).

Specifications

Power supply voltage	100-240VAC type DC 24V or AC 24V type
Operating frequency	50/60Hz
Operating voltage range	85 to 110% of the rated voltage
Environment temperature	-10 to 55°C (Avoid freezing or condensation)
Ambient humidity	RH 25 to 85% Max. 2,000mm
Altitude	Max. 2,000m
Characteristics	Thermocouple: (±0.5% of indication value or ±1°C, whichever greater) ±1 digit max. As follows the accuracy has the exceptions by temperature range. ±2°C ±1 digit max at K(-200 to 1300), or at less than -100°C of T,N ±2°C ±1 digit max at U and L No accuracy regulation at under 400°C of B ±3°C ±1 digit at less than 200°C of R and S Analog input: ±0.5%FS ±1digit max. Platinum resistance thermometer: (±0.5% of indication value or ±1°C, whichever greater) ±1 digit max. E5CZ-R2 / Q2 7VA(AC100-240V) E5CZ-□2M 7.5VA(AC100-240V) SVA(24V AC)/3W(24V DC)
Indication accuracy	Thermocouple: (±0.5% of indication value or ±1°C, whichever greater) ±1 digit max. As follows the accuracy has the exceptions by temperature range. ±2°C ±1 digit max at K(-200 to 1300), or at less than -100°C of T,N ±2°C ±1 digit max at U and L No accuracy regulation at under 400°C of B ±3°C ±1 digit at less than 200°C of R and S Analog input: ±0.5%FS ±1digit max. Platinum resistance thermometer: (±0.5% of indication value or ±1°C, whichever greater) ±1 digit max. E5CZ-R2 / Q2 7VA(AC100-240V) E5CZ-□2M 7.5VA(AC100-240V) SVA(24V AC)/3W(24V DC)
Power consumption	Platinum resistance thermometer Analog input Infrared Thermosensor ES1B Relay output: SPST-NO 250VAC,3A(resistive load) Voltage output: DC12V(21mA) Current output: DC4-20mA 6000 Relay output: 250VAC,1A(resistive load) 10,000 operations Control method ON/OFF or advanced PID
Sensor input	Platinum resistance thermometer Analog input Infrared Thermosensor ES1B Relay output: SPST-NO 250VAC,3A(resistive load) Voltage output: DC12V(21mA) Current output: DC4-20mA 6000 Relay output: 250VAC,1A(resistive load) 10,000 operations Control method ON/OFF or advanced PID
Control output	Platinum resistance thermometer Analog input Infrared Thermosensor ES1B Relay output: SPST-NO 250VAC,3A(resistive load) Voltage output: DC12V(21mA) Current output: DC4-20mA 6000 Relay output: 250VAC,1A(resistive load) 10,000 operations Control method ON/OFF or advanced PID
Alarm output	Platinum resistance thermometer Analog input Infrared Thermosensor ES1B Relay output: SPST-NO 250VAC,3A(resistive load) Voltage output: DC12V(21mA) Current output: DC4-20mA 6000 Relay output: 250VAC,1A(resistive load) 10,000 operations Control method ON/OFF or advanced PID
Mechanical life of relay	10 million operations
Electrical life of relay	100,000 operations
Control method	ON/OFF or advanced PID
Others:	Storage temperature -25 to 65°C (Avoid freezing or condensation) T2A, 250V AC, time-lag, low-breaking capacity
Recommended fuse	Approx. 150J (including Option Unit)
Weight	Approx. 140g (main unit only)
Degree of protection	Approx. 150J (including Option Unit) Front panel: IP50, Enclosure Category 2 (as per IEC60529)
Installation environment	Rear case: IP20, Terminal section: IP00 Installation category II, pollution degree 2 Indoor Use Only (as per IEC61010-1)
Memory protection	EEPROM (non-volatile memory) (Number of write operations: 1,000,000) Field wiring terminal
Terminal	

Operation menu

Input type

Input type	Input	Setting	Setting range		
Platinum resistance thermometer	Pt100	0	-200~850(°C) / -300~1500(°F)		
		1	-199.9~500.0(°C) / -199.9~900.0(°F)		
		2	0.0~100.0(°C) / 0.0~210.0(°F)		
		3	-199.9~500.0(°C) / -199.9~900.0(°F)		
Thermocouple	JP1100	4	0.0~100.0(°C) / 0.0~210.0(°F)		
		5	-200~1300(°C) / -300~2300(°F)		
		6	-20.0~500.0(°C) / 0.0~900.0(°F)		
		7	-100~850(°C) / -100~1500(°F)		
		8	-20.0~400.0(°C) / 0.0~750.0(°F)		
		9	-200~400(°C) / -300~700(°F)		
		22	-199.9~400.0(°C) / -199.9~700.0(°F)		
		Infrared Thermosensor ES1B	K	10	0~600(°C) / 0~1100(°F)
				11	-100~850(°C) / -100~1500(°F)
				12	-200~400(°C) / -300~700(°F)
				23	-199.9~400.0(°C) / -199.9~700.0(°F)
				N	13
R	14			0~1700(°C) / 0~3000(°F)	
S	15			0~1700(°C) / 0~3000(°F)	
B	16			100~1800(°C) / 300~3200(°F)	
10~70°C	17			0~90(°C) / 0~190(°F)	
60~120°C	18			0~120(°C) / 0~240(°F)	
115~165°C	19			0~165(°C) / 0~320(°F)	
140~260°C	20			0~260(°C) / 0~500(°F)	
Analog input	0~50mV	21	Use the following ranges for scaling: -1999 to 9999, -199.9 to 999.9 Vary Depending on "L", "H" value		

Default="5"

Alarms

Setting value	Alarm type	Alarm output function	
		Positive alarm value(X)	Negative alarm value(X)
0	No alarm function	Output off	
1	Upper- and lower- limit (deviation) *1	ON OFF	Vary with "L", "H" values
2	Upper-limit(deviation)	ON OFF	Vary with "L", "H" values
3	Lower-limit(deviation)	ON OFF	Vary with "L", "H" values
4	Upper- and lower-limit range (deviation) *1	ON OFF	Vary with "L", "H" values
5	Upper- and lower-limit with standby sequence(deviation)*1	ON OFF	Vary with "L", "H" values
6	Upper-limit with standby sequence(deviation)	ON OFF	Vary with "L", "H" values
7	Lower-limit with standby sequence(deviation)	ON OFF	Vary with "L", "H" values
8	Absolute-value upper-limit	ON OFF	Vary with "L", "H" values
9	Absolute-value lower-limit	ON OFF	Vary with "L", "H" values
10	Absolute-value upper-limit with standby sequence	ON OFF	Vary with "L", "H" values
11	Absolute-value lower-limit with standby sequence	ON OFF	Vary with "L", "H" values

Default="2"

Initial/Communication protect

Setting	Initial setting level	Communication Setting Level
0	Transition possible (Transition to Advanced function level possible)	Transition possible
1	Transition possible (Transition to Advanced function level not possible)	Transition possible
2	Transition not possible	Transition not possible

Default="1"


Setting change protect

Limits changes of setting by key operations.
ON: Key operations can be used to change settings
OFF: Key operations can not be used to change settings (Protect level settings can all be changed)


Other functions

In addition to the aforementioned, there are alarm hysteresis, automatic return of display mode and others in the advanced setting level. Refer to "E5CZ Manual" for details. For communications details, please refer to "E5AZ/EZ/CZ/PRR communications User's Manual".

Initial setting level control stopped *4




Communication setting level





AT (Auto Tuning)

AT in Adjustment
Designated "on" to execute AT and "off" to cancel AT.
Also when AT execution ends, the display automatically returns to "off".

POWER ON




Protect level



Use the following key operations for transition between levels:
Operation level → Protect level:
[] + [] keys for at least 3 seconds
Operation level → Adjustment level:
[] key for less than 1 second
Operation level → Initial level:
[] key for at least 3 seconds
Operation / Adjustment protect
The following table shows the relationship between settings and protect levels related to Operation level and Adjustment level.

*No protect when set to "0"
Default="0"

Adjustment level



Error display (trouble shooting)

When an error has occurred, the No.1 display alternately indicates error codes together with the current display item.

No. 1 display	Meaning	Action	Control output	Alarm output
5Err (S.Err)	Input error *2	Check the wiring of inputs, disconnections, shorts and input type.	OFF	Operates as above upper limit
	A/D converter error *2	After the correction of input error, turn the power Off then back On again. If the display remains the same, the controller must be changed. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.	OFF	OFF
E111 (E111)	Memory error	First, turn the power Off then back ON again. If the display remains the same, the controller must be changed. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.	OFF	OFF
HErr (H.Err)	Internal circuit error *2	Continue to controlling, run normally. If show the "Heater current monitor", it will display the wrong information.	ON	ON

If the input value exceeds the display limit (-1999(-199.9) to 9999(999.9)), though it is within the control range, [] will be displayed under -1999(-199.9) and [] above 9999(999.9). Under these conditions, control output and alarm output will operate normally.

The check list when the problem happen

Appearance	Cause
Though the control object temperature has changed, the displayed temperature was not changed.	When the used sensor is PT, the setting of input type is Thermocouple. The sensor is TC type but the sensor short.
The displayed temperature is higher (or lower) than the control object temperature.	The temperature input shift setting is not suitable. Thermocouple connection polarity is wrong.
Can not start temperature control.	"RUN/STOP" function is set to "STOP". "Proportional band" setting is too big. The setting of "Direct operation/Reverse operation" is wrong. (Ex: To control the heater, but set to "Direct operation")
Key switch is not function.	"Set point limits" function limits to change the set point. Operation protect function is working.

- *1: Upper and lower limits can be set for parameters 1.4 and 5 to provide for different types of alarm. These are indicated by the letter "L" and "H".
- *2: Error shown only for "Process value / Set point". Not shown for other status.
- *3: Refer to the adjoining tables for details of input types and alarm types.
- *4: Controller does not operate during initial setting level. (Process will be stopped)
- *5: Some setting items may not be displayed according to the setting.
- *6: Applicable only to models with the heater burnout alarm function.
- *7: Applicable only to models with a communications function.
- *8: Applicable only to models with event function.
- *9: E5CZ-R2/Q2 can not use the function of *6,*7,*8; E53-CN□N is applicable only to models of E5CZ-□2M.

Link Way

OMRON ELECTRONICS PTE LTD(SINGAPORE)
PHONE: 65-6547-6789
OMRON ELECTRONICS LTD.(NEW ZEALAND)
PHONE: 64-9-358-4400

OMRON ELECTRONICS PTY. LTD.(AUSTRALIA)
PHONE: 61-2-9878-6377
OMRON ELECTRONICS SDN.BHD.(MALAYSIA)
PHONE: 60-3-7628-9388

PT. OMRON ELECTRONICS(INDONESIA)
PHONE: 62-21-8370-9555
OMRON ELECTRONICS CO.,LTD.(THAILAND)
PHONE: 66-2-937-0500